

CERAMIC GLASS COAT

APPLICATION INSTRUCTIONS

IMPORTANT

THIS IS A PERMANENT PRODUCT. FOLLOW ALL INSTRUCTIONS!

1. Apply **Step 1 Glass Cleaner Wipe** onto clean window, scrubbing thoroughly. Use 1 wipe per each half of windshield.
2. Allow Glass Cleaner to sit for 2 minutes.
3. Rinse extremely well with running water, ensuring no cleaner is left on window or surrounding surfaces.

Note: *If Step 1 Cleaner gets on anything but glass, don't worry, just wipe it off immediately with a clean damp cloth.*

4. Dry glass **completely**, any water present will negatively affect coating.
5. Dispense a small line of **Step 2 Ceramic Glass** Coating along the entire length of the provided Microfiber Applicator Sponge. Apply using a cross hatch (#) pattern, first using vertical lines, then horizontal lines. Dispense additional coating onto the Applicator Sponge as needed, ensuring the applicator stays wet until the entire windshield is coated. Any remaining coating can be used at a later time.
6. Allow coating to cure for 5-10 minutes.
7. Buff off with the provided finishing towel, switching sides of the towel to completely buff the glass clean.

Note: *If Step 2 Glass Ceramic gets on anything but glass, don't worry, just wipe it off immediately with a clean dry cloth.*

8. **DO NOT** expose to moisture for at least 1 hour, allow 24 hours before washing.

CERAMIC GLASS COAT APPLICATION INSTRUCTIONS

IMPORTANT

**THIS IS A PERMANENT PRODUCT.
PLEASE FOLLOW ALL INSTRUCTIONS!**

**ALWAYS WEAR CHEMICAL RESISTANT
GLOVES WHILE HANDLING.**

**SCAN FOR
INSTRUCTIONAL VIDEO**



CERAKOTE
CERAMIC COATINGS



Application Videos and Tips:
CerakoteCeramics.com

Call for help or questions:
866.774.7628

DANGER: Keep out of reach of children. Eye & skin irritant, flammable liquid & harmful vapor. **Read all cautions and instructions prior to use.** For complete SDS and guarantee details visit cerakoteceramics.com