

IMPORTANT

READ ALL INSTRUCTIONS BEFORE STARTING

WE STRONGLY RECOMMEND WATCHING THE INSTRUCTIONAL VIDEO, WHICH VISUALLY SHOWS THIS PROCESS.



TAKE A "BEFORE" PHOTO OF YOUR HEADLIGHT to document the incredible before and after results

Note:

- For best results, Cerakote Headlight restoration should be done in the shade.
- A spray bottle with water or a hose and several clean dry towels are needed.

STEP 1

- Before starting and if applicable, open the hood for easier access to the headlights.
- Wash headlights thoroughly with any type of car soap and rinse well.
- Put on supplied gloves.
- Using an Oxidization Remover wipe, rub each headlight in a circular, scrubbing motion on all areas of the lens. During this process any oxidization in the lens will be extracted which will turn the wipes yellow. Move to the next Oxidization Remover wipe when the current wipe becomes yellow and soiled. Use (4) wipes per headlight to ensure your headlight is as clean as possible. Don't worry if your fourth wipe is still yellow as the next step will remove any remaining oxidization.

Note: If Oxidization Remover gets on your paint, don't worry just wipe it off immediately with a clean dry towel.

Note: You will want to do both headlights with all the Step 1 wipes before proceeding to Step 2.

- Rinse thoroughly.
- After you have completed Step 1, remove and discard your gloves

Note: When Step 1 is complete, your headlights should have a cloudy look.

NEED HELP?

For help or to see other Automotive and Home products visit www.cerakoteceramics.com or call us at:

866.774.7628

STEP 2

- Fasten the **Red** disc to the Surface Prep Pad. (Be careful not to sand the paint or surrounding areas)

Note: In some cases, it may be necessary to remove the Surface Prep Discs from the Surface Prep Pad to get into hard to reach areas. Extra effort on this step will give you the best possible results.

- Wet the headlight lens and Surface Prep Disc with water (a squirt bottle works well) and scrub the entire lens in a uniform, **non-circular motion** for approximately **2 to 3 minutes**. Be sure to keep the lens wet during this time! Upon completion, rinse well with water.
- Fasten the **Grey** disc to the Surface Prep Pad and repeat the previous process.

- Rinse the headlights and surrounding areas well with water **and dry with a clean soft towel. Use multiple towels to ensure the headlights are dry. The headlights and surrounding areas must be completely dry before starting Step 3.**

Note: When Step 2 is complete, your headlights should have a clouded, frosted appearance. More surface prep is needed if areas are clear or shiny.

VERY IMPORTANT: THE CERAMIC CLEAR COATING IS NOT COMPATIBLE WITH WATER. THE HEADLIGHT AND SURROUNDING AREA MUST BE COMPLETELY DRY OR YOU WILL DAMAGE YOUR HEADLIGHT LENS.

STEP 3

- **Put on the second pair of clean gloves** and open one of the Cerakote Ceramic Clear Coat wipes. **Moving horizontally from top to bottom**, carefully wipe the coating in a single direction using a 50% overlapping technique. **ONLY APPLY A SINGLE COAT.**

- Repeat this process with the second wipe on the other headlight.

- Allow the Cerakote Ceramic Clear Coating to dry for a minimum of **60 minutes** before driving or exposing them to any moisture.

Note: If the Clear Coat gets on paint, don't worry. Just wipe it off immediately with a clean dry towel.

Congratulations! You have clarified, restored and protected your headlights for life.*



TAKE AN "AFTER" PHOTO OF YOUR HEADLIGHT



SUBMIT YOUR REVIEW WITH YOUR "BEFORE AND AFTER" PHOTOS TO AMAZON!

*FOR COMPLETE SDS AND LIMITED WARRANTY DETAILS, VISIT WWW.CERAKOTECERAMICS.COM